

2008-18 CHEVY/GMC

TRIM TO FIT - SHORT BED INSTRUCTION



USE TRIM LINES 1, 9, 13 AND 14

Part# 16011

