

2008-18 CHEVY/GMC

TRIM TO FIT - STANDARD BED INSTRUCTION



USE TRIM LINES 1, 11, 12, 18 AND 21